

CEW TEST CHAMBER MOUNTING INSTRUCTIONS

YOU WILL REQUIRE THE FOLLOWING TOOLS TO COMPLETE THE INSTALLATION:

- PENCIL
- LEVEL
- DRILL
- TAPE MEASURE
- (4) FLAT HEAD SCREWS & WASHERS



STEP 1

AFTER DETERMINING THE MOUNTING LOCATION, MAKE A MARK ON THE WALL 64" FROM THE FLOOR.



STEP 4

USE AT MINIMUM 2" SCREWS DESIGNED FOR THE MOUNTING SURFACE, OR DRYWALL ANCHORS.



STEP 2

USING A LEVEL, DRAW A STRAIGHT LINE APPROX. 10" (25CM) LONG THROUGH THE MARK YOU JUST MADE.



STEP 5

WHILE SOMEONE HOLDS THE BOX, FASTEN ALL 4 SCREWS AT EACH CORNER.



STEP 3

ALIGN THE TOP OF THE BOX WITH THE LINE. WHILE ANOTHER PERSON HOLDS THE BOX, DRILL 4 HOLES.



STEP 6

REMOVE THE TAPE BACKING ON THE TESTING SHEET AND APPLY TO THE WALL DIRECTLY ABOVE THE BOX.



FOR A HIGH RESOLUTION COPY OF THIS DOCUMENT, GO TO RAMPARTCORP.COM/CEW-DOCS